

## Instructions on how to operate a manual smoke vent

### Heysmoor Heights

The below are photographs of the manual switches which can be used to activate the smoke vents at the top of the stairwell and in the communal lobby areas on the 15<sup>th</sup> and 16<sup>th</sup> floors. These switches are located on the ground floor by the protected stairwell fire door.

The yellow boxes are clearly labelled for each vent. For the vents on the 15<sup>th</sup> and 16<sup>th</sup> floors, open the clear cover and press down the switch labelled 'open'.

For the staircase vent, press firmly in the centre of the clear plastic cover to break this then press the orange button in the centre of the yellow box.

